



DATA SHEET No. ICO1857  
Rev. 11/08

**Monarflex**  
Geomembranes



**NBS**

## Reflex Super - Welded

Application: Perimeter Membrane / Infill Membrane

Project: Housing (Timber Frame)

### J40 FLEXIBLE SHEET TANKING/DAMP PROOF MEMBRANES

To be read with Preliminaries/General conditions.

### 145 WELDABLE POLYETHYLENE GAS RETARDANT/DAMP PROOF MEMBRANE:

Manufacturer and reference: Icopal Monarflex Geomembranes Ltd, Monarflex Geomembranes Ltd, PO Box 6318, Leighton Buzzard, LU7 6AN  
Telephone: 08444 123 175 Fax: 01525 384 477

- Thickness/gauge: [0.45] Weight: [500 gsm] BBA certificate: [00/3668]
- Lay sheets neatly and tuck well into angles to prevent bridging and creasing.
- Joint sheets by Monarflex extrusion welding system with laps of not less than 150 mm.
- Where fixings occur through membrane, 70mm Monobond tape to be applied locally at point of fixing penetration.
- Form internal and external corners using [Monarseal Self Adhesive gas membrane] to Monarflex Geomembranes Ltd standard working details
- All pipe and duct penetrations to be sealed using RAC 0.9mm preformed Top Hats complete with stainless steel jubilee clips.
- All steel columns, concrete penetrations etc to be sealed to using [Monarseal Self Adhesive Gas Membrane] to Monarflex Geomembranes Ltd standard working details
- All materials to be installed by Monarflex Geomembranes Ltd to ISO 9001.2000 using BBA certified products where applicable.

### 180 SELF-ADHESIVE BITUMEN GAS RETARDANT/DAMP PROOF MEMBRANE/TANKING:

- Manufacturer and reference: [Monarseal Self Adhesive gas membrane]
- Primer: As clause 330.
- Number of layers: One.
- Laps: Not less than recommended by sheet manufacturer.
- Bonding: Apply sheets adhesive side down, smoothing out to exclude air. Roll laps to ensure good adhesion between sheets.



DATA SHEET No. ICO1857  
Rev. 11/08

**Monarflex**  
Geomembranes



## NBS

# Reflex Super - Welded

Application: Perimeter Membrane / Infill Membrane

Project: Housing (Timber Frame)

### 310

#### **WORKMANSHIP GENERALLY:**

- Apply materials carefully to provide a completely impervious, continuous membrane.
- Ensure that surfaces to be covered are clean, dry, smooth and free from voids, sharp protrusions and frost.
- Protect finished sheeting adequately to prevent puncturing during following work.
- Cover sheeting with permanent overlying construction as soon as possible. Immediately prior to covering check for damage and repair as necessary.

### 320

#### **INSPECTION:**

Inform CA a reasonable length of time before covering any part of membrane with overlying construction, to allow inspection.

### 330

#### **PRIMER(S):**

Type(s) recommended for the purpose by the sheet manufacturer. Apply by mopping, brushing or spraying to achieve an even and full cover of the surface. Allow to dry thoroughly before covering.